


# STANLEY®

## 4 Gal (15Litre) ASH VACUUM OWNER'S MANUAL



**IMPORTANT: READ THIS OPERATOR'S MANUAL  
BEFORE USING!**

## TABLE OF CONTENTS

---

Specifications-----	3
Package Contents-----	4
Safety Information-----	5
Operating Instructions-----	7
Care and Maintenance -----	8
Troubleshooting-----	8
Exploded View and Parts List-----	9
Warranty-----	10

**To order replacement bag, filters or parts contact;**



Customer Service

**AUS 1300 660 457**  
**NZ 0800 474 876**

**email: [service.group@smga.com.au](mailto:service.group@smga.com.au)**

---

## INTRODUCTION

Dear Customer,

Thank you for purchasing this wet/dry vacuum which has passed through our extensive quality assurance processes. Every care has been taken to ensure that it reaches you in perfect condition. However, in the unlikely event that you should experience a problem, or if you require any assistance please do not hesitate to contact us;

## PRODUCT SPECIFICATIONS

---

Power	240V / 50Hz / 600Watt
Motor	Single Stage
Tank capacity	15 Litre
Hose	1.2 m x 3.2 cm
Power cord	H05VV-F 2 x 0.75mm <sup>2</sup> x 2.4m

### **WARNING:**

Use only extension cords that are rated for outdoor use. Extension cords in poor condition or that are too small in wire size can pose fire and shock hazards.

 **If you have a problem, call customer service do not return this wet/dry vacuum to the place of purchase.**

**For any queries or assistance call**



Customer Service

**AUS 1300 660 457**  
**NZ 0800 474 876**

Hours of operation:  
Monday to Friday  
8.00am - 5.00pm AEST

**Do not return to place of purchase.**

Keep your purchase receipt, this will be required to make any claims under the 12 month warranty.

**Please take note of serial number and write here for ease of reference:**


**Serial Number:** \_\_\_\_\_

**Date of Purchase:** \_\_\_\_\_

**Place of Purchase:** \_\_\_\_\_

**Receipt Number:** \_\_\_\_\_


**PACKAGE CONTENTS**




**A**



**B**



**C**



**D**

<b>PART</b>	<b>DESCRIPTION</b>	<b>QTY</b>
1	Handle	1
2	Power switch	1
3	Lid latch	2
4	Vacuum port	1
5	Dust tank	1

<b>PART</b>	<b>DESCRIPTION</b>	<b>PART NO</b>	<b>QTY</b>
A	Metal hose	25-1043	1
B	Aluminum extension wand	25-1042	1
C	Pre-filter	25-1040	1
D	Cartridge filter	25-1041	1

## SAFETY INFORMATION

---

### IMPORTANT SAFETY INSTRUCTIONS & GROUNDING INSTRUCTIONS

When using an electrical appliance, basic precautions should be always followed, including the following: **READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE.**

#### ATTENTION:

Read all safety rules carefully before attempting to operate. Retain for future reference.

#### DANGER:

Never operate this unit when flammable materials or vapors are present because electrical devices produce arcs or sparks that can cause a fire or explosion.

### NEVER OPERATE UNATTENDED!

#### WARNING:

**To reduce the risk of fire, electric shock, or injury:**

1. Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
2. Do not use on wet surfaces. Do not expose to rain. Store indoors.
3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
4. Use only as described in this manual, Use only Manufacturer's recommended attachments.
5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors or dropped into water, contact service center for assistance.
6. Do not: pull or carry by cord, use cord as a handle, close a door or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
8. Do not handle plug or appliance with wet hands.
9. Do not put any object into openings. Do not use with any openings blocked; keep free of dust, lint, hair and anything that may reduce air flow.
10. Keep hair, loose clothing, fingers and all parts of body away from openings and moving parts.
11. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
12. Do not use without filters in place.
13. Turn off all controls before unplugging.
14. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
15. Do not use the ash vacuum as a sprayer of flammable liquids such as oil-based paint, lacquers, etc.
16. Do not vacuum toxic, carcinogenic, combustible or other hazardous materials such as asbestos, arsenic, barium, beryllium, lead, pesticides or other health endangering materials Specially designed units are available for these purposes.
17. Do not pick up ash without cartridge and pre-filter in place. These are very fine particles that may pass through the motor and affect the performance of the motor or be exhausted back into the air.
18. Do not leave the cord lying on the floor once you have finished the cleaning job. It can become a tripping hazard.
19. Use special care when emptying heavily loaded tanks.
20. To avoid spontaneous combustion, empty tank after each use.
21. The operation of ash vacuum can result in foreign objects being blown into eyes, which can result in eye damage. Always wear safety goggles when operating vacuum.
22. **STAY ALERT.** Watch what you are doing and use common sense. Do not use ash vacuum when you are tired, distracted or under the influence of drugs, alcohol or medication causing diminished control.
23. **DO NOT** use this ash vacuum to vacuum lead paint debris because this may disperse fine lead particles into the air. This ash vacuum is not intended for use under EPA Regulation 40 CFR Part 745 for lead paint material cleanup.

## SAFETY INFORMATION

---


24. This appliance is provided with double insulation. Use only identical replacement parts. See instructions for servicing double insulated appliances.
25. Unplug before connecting the hose, wand and the like.

### CAUTION:

In case of excessive temperatures, the dust tank, the filters, or the ash vacuum may be damaged. Completely empty the ash vacuum and the filter in a safe area after the vacuum cleaning. Let both appliances (vacuum and filter) cool down under supervision.

### WARNING:

#### **SERVICING ASH VACUUM**

In a double-insulated ash vacuum, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added. Servicing a double-insulated ash vacuum requires extreme care and knowledge of the system and should be done only by qualified service personnel. Replacement parts for a double-insulated ash vacuum must be identical to the parts they replace. Your double-insulated ash vacuum is marked with the words "DOUBLE INSULATED" and the symbol  (square within a square) may also be marked on the appliance.

To reduce the risk of injury from electrical shock, unplug power cord before servicing the electrical parts of the ash vacuum.

### **IMPORTANT!**

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

### **IMPORTANT!**

Remove the plug from the socket before performing maintenance. Before using the machine make sure that the frequency and voltage shown on the rating plate correspond with the mains voltage. Specifications and details are subject to change without prior notice. The accessories shown in the pictures may vary from model to model.

### **IMPORTANT SAFEGUARDS**

The symbol on the product or packaging indicates that the product must not be treated as domestic refuse. Instead, it should be handed in to a collection point for the recycling of electrical and electronic components. By ensuring the product is treated in the correct manner, you will help prevent any negative impact on the environment and health that might arise were the product to be discarded as ordinary refuse. For further information about recycling, you should contact your local authorities, refuse collection service or the sales outlet where you bought the goods.



## **OPERATING INSTRUCTIONS**

---

### **⚠ WARNING:**

To reduce the risk of fire or explosion, do not operate this vacuum in areas with flammable gases, vapors or explosive dust in the air. Flammable gases or vapors include but are not limited to: lighter fluid, solvent-type cleaners, oil-based paints, gasoline, alcohol or aerosol sprays. Explosive dusts include but are not limited to: coal, magnesium, aluminum, and grain or gun powder. Do not vacuum explosive dust, flammable or combustible liquids or hot ashes. Do not use this vacuum as a sprayer for any flammable or combustible liquid. To reduce the risk of health hazards from vapors or dusts, do not vacuum toxic materials.

### **⚠ WARNING:**


The operation of ash vacuum can result in foreign objects being blown into the eyes, which can result in severe eye damage. Always wear safety eyewear complying with ANSI Z87.1 or in Canada, CSA Z94.3 before starting operation.

### **⚠ CAUTION:**

To reduce risk of hearing damage, wear ear protectors when using the vac vacuum for extended hours or when using it in a noisy area.

This 15 liter ash vacuum is assembled at the factory and ready for use when you remove it from the carton. The unit is ready for dry cold ash vacuuming After you plug the power cord into the wall receptacle, turn the unit "ON" by pushing the switch from position "O" to position "I". The "O" is the "OFF" position and the "I" is the "ON" position.

**O = OFF I = ON**



### **ASH PICK-UP**

The cartridge filter and pre-filter must always be in correct position to reduce the risk of leaks and possible damage ash vacuum. Make sure that the cartridge filter is completely covering the filter cage. Make sure there are no gaps between the cartridge filter and the lid. And make sure the pre-filter is completely covering the opening edge of dust tank. Make sure there are no gaps between the pre-filter and the dust tank. It is very important to assemble the cartridge filter to the cage and pre-filter to the dust tank without allowing any possible leaks or tears. Any leaks will allow the picked up debris to be blown out of the exhausting openings and back into the surrounding environment. And also damage the motor as well.

### **NOTE:**


The ash vacuum only be used for dry cold ash material. When the filter is wet, the filter will clog quickly and be very difficult to clean. So if the filter get wet, replace it before continuing to do ash pickups.

### **EMPTY THE TANK**

#### **⚠ WARNING:**

To reduce the risk of injury from accidental starting, unplug power cord before emptying the dust tank.

1. Remove the power head assembly of the ash vacuum by pulling outward on the lid clips located on each side of the ash vacuum. Lift off the power head assembly.
2. Dump the tank contents into the proper waste disposal container.



## CARE AND MAINTENANCE

---

### FILTER REPLACEMENT

**⚠ WARNING:** To reduce the risk of injury from accidental starting, unplug power cord before changing or cleaning the cartridge filter and pre-filter.

The filters should be cleaned often to maintain peak vacuum performance.

**⚠ IMPORTANT:** After cleaning, check the cartridge filter and pre-filter for tears or small holes. Do not use a filter with holes or tears in it. Even a small hole can cause a lot of ash dust to come out of the ash vacuum. Replace it immediately.

**NOTE:** Before installing the cartridge filter on the ash vacuum, clean the area of the lid so that the cartridge filter will seal against the lid and stop small particles from bypassing the filter. If the cartridge filter is clean and not damaged, place it on the filter cage. If it cannot be reused, replace a new filter over the filter cage.

#### NOTE:

Clean the filter in an open area. Cleaning should be done outdoors and not in living quarters.

**⚠ WARNING:** Do not remove filter cage. The cage prevents fingers from touching the moving impeller.

### CLEANING

To keep the ash vacuum looking its best, clean the outside with a cloth dampened with warm water and mild soap.

To clean the tank:

1. Dump out debris.
2. Wash tank thoroughly with warm water and mild soap.
3. Wipe out with dry cloth.

### STORAGE

Before storing the ash vacuum, the dust tank should be emptied and cleaned. The accessories should be kept in the accessory holder so they can be readily available. The ash vacuum should be stored indoors.

## TROUBLESHOOTING

---


### ⚠ WARNING :

Minor problems often can be fixed without calling customer service.

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Vacuum does not run	1.No electricity. 2. Motor temperature come to its stop-actuation temperature.	1.Make sure electrical outlet has voltage. (A qualified electrician may need to be contacted) 2. Restart unit after the motor temperature cool down.
Loss of suction	1. Full tank. 2. Clogged hose. 3. Clogged filter.	1. Empty and clean tank. 2. Remove hose and clean debris. 3. Clean or replace filter.



## EXPLODED VIEW / PARTS LIST



PART	DESCRIPTION	QTY
1	Handle	1
2	Power switch	1
3	Top cover	1
4	Motor holder	1
5	Motor	1
6	Motor seals ring	1
7	Middle frame	1

PART	DESCRIPTION	QTY
8	Inlet filter	1
9	Cartridge filter	1
10	Pre-filter	1
11	Power cord	1
12	Cord clamp	1
13	Tank	1
14	Vacuum port	1

## **WARRANTY**

---

### **EXPRESS WARRANTY STATEMENT WET/DRY VACUUM**

You are not required to do anything to register your wet/dry vacuum purchase. Please attach the purchase receipt to this manual and ensure both are kept safe. We hope you enjoy your new wet/dry vacuum, and if you have any problems call customer service on the above phone numbers. Do not return to place of purchase.

Smart Marketing Group Pty Ltd (SMG) warrants that this wet/dry vacuum will be free from manufacturing faults or defects for 12 months from the date of purchase, providing original purchase receipt is kept and shown when needed and is subject to the terms and conditions below.

If a warranty fault appears within the warranty period, SMG reserves the right to replace or repair the product. In the event that SMG chooses to replace the product, this original warranty will expire at the original date. If the product includes various accessories or components, only the defective accessory or component will be replaced or repaired. SMG reserves the right to replace defective parts of the product with parts and components of similar quality, grade and composition where an identical part or component is not available. Products presented for repair may be replaced by refurbished products of the same type rather than being repaired. Refurbished parts may be used to repair the products.

#### **WHAT IS COVERED**

- Manufacturing fault or defect.

#### **HOW TO CLAIM UNDER THIS WARRANTY**

- Call customer service.
- Ensure you have the following: Original purchase receipt, Model of wet/dry vacuum, Serial number of wet/dry vacuum.
- Discuss the issue.
- Customer service will advise which authorised service agent to take the wet/dry vacuum to provided the issue is a warranty one.
- Take wet/dry vacuum to authorised service agent for repair.

#### **WHAT IS NOT COVERED**

- Use of wet/dry vacuum for hire.
- Commercial use of wet/dry vacuum.
- Use of wet/dry vacuum in a commercial application.
- Damage or deterioration due to transport.
- Damage caused by negligence, misuse, abuse or accident or incorrect voltage and wattage.
- Any corrosion or rusting.
- Damage caused by incorrect set up and start up.
- Replacement parts due to general wear and tear.
- Wet/dry vacuum with serial number defacement, modification or removal.
- Wet/dry vacuum which have been serviced by other than an authorised SMG service agent.
- Wet/dry vacuum with no original purchase receipt.
- Wet/dry vacuum which have been on sold, not original purchaser.
- Damage due to non-servicing of wet/dry vacuum as is required by this manual.
- Blockages / damage caused by dust, dirt, spiders webs or insects.
- Damage caused by the incorrect fitting of accessories.
- Damage caused by overloading, overworking the wet/dry vacuum.
- Damage to attached equipment or third party accessories.
- Damage caused by attached equipment or third party accessories.

#### **CONTACT DETAILS**

Smart Marketing Group Pty Ltd  
33-35 Lionel Road, Mt. Waverley,  
Victoria 3149, Australia.  
AUS 1300 660 457  
NZ 0800 474 876  
service.group@smga.com.au

## **WARRANTY**

---

### **COMPLETE WARRANTY STATEMENT – WET/DRY VACUUM**

As soon as you have purchased the wet/dry vacuum, we recommend that you check to make sure it is intact and that you read the operating instructions carefully before using it. The purchase receipt for this product is to be retained and must be presented if making a claim under the terms of the Smart Marketing Group (SMG) warranty. Bank account statements are not acceptable for proof of purchase.

This warranty does not cover wet/dry vacuum intended for hire or use in commercial applications or in commercial premises. The warranty will under no circumstances extend to reimbursement or payment of damages, whether direct, indirect or consequential.

The warranty is void if there is evidence the wet/dry vacuum has been modified or tampered with in any way or used with unauthorised accessories without our consent.

SMG declines any responsibility or liability whatsoever arising from misuse or abuse, negligent handling of the wet/dry vacuum or if the product has not been installed or failure to comply with the relevant safety, operating, setting and maintenance instructions (see further in this manual). The warranty does not extend to installation or disconnection costs.

Any item sent freight forward/collect for repair will be refused. Warranty repairs are free of charge, provided the product is delivered to our service department or authorised service agent. The wet/dry vacuum will need to be returned, adequately protected in a box. SMG will not be responsible for any in-transit loss or damage. Assistance under the warranty will only be made available if the request is made to our customer service team on the contact numbers listed below and proof of purchase is provided.

This is a repair only warranty you will need to take the wet/dry vacuum to the authorised service agent after contacting our customer service centre.

If the product includes various accessories or components, only the defective accessory or component will be replaced or repaired.

SMG reserves the right to replace defective parts of the product with parts and components of similar quality, grade and composition where an identical part or component is not available. Products presented for repair may be replaced by refurbished products of the same type rather than being repaired. Refurbished parts may be used to repair the products.

Damage caused by third party accessories is not covered under this warranty. Damage caused to attached equipment or third party accessories will not be covered under this warranty. Rust and corrosion are not covered under this warranty.

If a warranty fault is found the freight cost will be credited to the owner. If no fault is found the product will be returned and any costs associated with the service will be charged to the owner. Blockages caused by spider webs, insects, dirt, accumulated dust, incorrect voltage and wattage are not covered by this warranty.

SMG reserves the right to replace or repair the product within the warranty period. Parts found to be defective due to a manufacturing fault will be replaced free of charge.

In the event of SMG choosing to replace the product, the warranty will expire at the original date of purchase. If no warranty fault is found the owner will be advised and the product will be returned and any costs associated with the service will be charged to the owner.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits of this warranty are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded.

In New Zealand, this SMG warranty is in addition to the conditions and guarantees which are mandatory as implied by the New Zealand Consumer Guarantee Act 1993. For service, spare parts or product information please contact customer service:

Australia: 1300 660 457

New Zealand: 0800 474 876

Do not return to place of purchase.

Smart Marketing Group Pty Ltd

Customer Service

Australia: 1300 660 457

New Zealand: 0800 474 876

Operating times: Monday – Friday 8.00am - 5.00 pm

Australian Eastern Standard Time (AEST)

33-35 Lionel Road, Mt. Waverley

Victoria 3149, Australia.

Stanley® and **STANLEY** are trademarks of Stanley Black & Decker, Inc.,  
or its affiliates and are used under license by Alton Industry Ltd. Group

The Stanley Black & Decker, Inc.

New Britain, CT 06053 U.S.A

<http://www.stanleyblackanddecker.com>